

-Line interactive UPS-
UA Series 0.4~2kVA 1:1phase PF:0.6



Features

- AVR boost and buck
- Cold start function
- Smart RS-232/USB interface for power management
- Built-in self-diagnostic function
- Modem/LAN internet protection
- Generator compatible(Optional)
- LCD or LED panel for option
- Fast charging capacity
- Auto charging at off mode
- Auto restart while AC is recovering



Two kinds of color LCD display

LED display

1. AC input
2. Output socket
3. USB & RJ11 communication
4. USB & RS232 communication
5. RJ45



Optional socket



Rear Panel

Technical Specifications

| Model | UA40 | UA60 | UA80 | UA100 | UA120 | UA150 | UA200 |
|-----------------------------------|---|----------------|-----------------|-------------------|-----------------|-----------------|-----------------|
| Capacity(VA/Watts) | 400 / 240 | 600 / 360 | 800 / 480 | 1000 / 600 | 1200 / 720 | 1500 / 900 | 2000 / 1200 |
| INPUT | | | | | | | |
| Nominal Input Voltage | 110/120 Vac or 220/230/240 Vac | | | | | | |
| Operating Voltage Range | 81~145 Vac / 162~290 Vac | | | | | | |
| Operating Frequency Range | 50/60 Hz (1 ± 10%) | | | | | | |
| OUTPUT | | | | | | | |
| Output Voltage range (Batt. Mode) | Simulated Sinewave at nominal voltage ± 10% | | | | | | |
| Frequency Range (Batt. Mode) | 50 Hz or 60 Hz ± 1 Hz | | | | | | |
| Transfer Time | Typical 2~6 ms, 10ms max. | | | | | | |
| BATTERY | | | | | | | |
| Battery Type & Number | 12 V / 4.5 Ah x 1 | 12 V / 7Ah x 1 | 12 V / 9 Ah x 1 | 12 V / 7 Ah x 2 | 12 V / 7 Ah x 2 | 12 V / 9 Ah x 2 | 12 V / 9 Ah x 2 |
| Typical Recharge time | 6~8 hours (To 90% capacity) | | | | | | |
| PROTECTION | | | | | | | |
| Full Protection | Overload and overcharge protection | | | | | | |
| INDICATORS | | | | | | | |
| LED (LED version) | AC Mode, Battery Mode, Load Level, Battery Level | | | | | | |
| LCD (LCD version) | AC Mode, Battery Mode, Load Level, Battery Level, Input Voltage, Output Voltage, Overload, Fault, Battery Low | | | | | | |
| ALARM | | | | | | | |
| Battery Mode | Sounding every 10 seconds | | | | | | |
| Battery Low | Sounding every second | | | | | | |
| Overload | Sounding every 0.5 second | | | | | | |
| Battery Replacement Alarm | Sounding every 2 seconds | | | | | | |
| Fault | Continuously sounding | | | | | | |
| MANAGEMENT | | | | | | | |
| USB & RS-232 port (Optional) | Supports Windows® 2000/2003/XP/Vista/2008, Windows® 7, Linux, Unix, and MAC | | | | | | |
| ENVIRONMENT | | | | | | | |
| Operating Temperature | 0~40℃ | | | | | | |
| Humidity Range | 0~95 % (Non-condensing) | | | | | | |
| Noise Level | <40dB (1 meter from surface) | | | | | | |
| PHYSICAL | | | | | | | |
| Dimension, W × D × H (mm) | 101 × 298 × 142 | | | 149.3 × 338 × 162 | | 158 × 380 × 198 | |
| Net Weight (kg) | 3.55 | 4.25 | 4.9 | 7.8 | 8 | 11.1 | 11.5 |
| STANDARDS | | | | | | | |
| Safety | IEC/EN62040-1;IEC/EN60950-1 | | | | | | |
| EMC | IEC/EN62040-2;IEC61000-4-2;IEC61000-4-3;IEC61000-4-4;IEC61000-4-5;IEC61000-4-6;IEC61000-4-8 | | | | | | |

Specifications are subject to change without prior notice.

ОФИЦИАЛЬНЫЙ ДИЛЕР В УКРАИНЕ:

storgom.ua

ГРАФИК РАБОТЫ:

Пн. – Пт.: с 8:30 по 18:30

Сб.: с 09:00 по 16:00

Вс.: с 10:00 по 16:00

КОНТАКТЫ:

+38 (044) 360-46-77

+38 (066) 77-395-77

+38 (097) 77-236-77

+38 (093) 360-46-77

Детальное описание товара:

<https://storgom.ua/product/istochnikbespereboynogopitaniiakstarua60.html>

Другие товары: <https://storgom.ua/istochniki-bespereboinogo-pitaniia-ibp.html>